



NOTE: WHEN ONLY THE PIEZO/MONO JACK IS CONNECTED, THE MIX POT CONTROLS THE MAXIMUM LEVEL OF THE PIEZO SIGNAL. WHEN THE MAGNETIC/STEREO JACK IS CONNECTED, THE MIX POT IS DISABLED.

<b>ERNIE BALL / MUSIC MAN</b>			
JP BFR, JPXI, JP12 7-STRING CONTROL FUNCTION DIAGRAM			
REV —	DRAWN BY DTM	APPROVED BY JHW	DATE 01-16-12
SCALE NONE	TOLERANCE	N/A	PART NO.

MAGNETIC/STEREO OUTPUT-

WHEN USED WITH A MONO CABLE, THIS OUTPUT PROVIDES A PASSIVE SIGNAL FROM THE MAGNETIC PICKUPS ONLY.  
WHEN USED WITH A STEREO (TRS) CABLE, TIP OUTPUTS PASSIVE MAGNETIC SIGNAL; RING OUTPUTS BUFFERED PIEZO SIGNAL.

PIEZO/MONO OUTPUT-

USE MONO CABLE ONLY.  
WHEN ONLY THIS JACK IS CONNECTED, A BUFFERED AND MIXED COMBINATION OF THE MAGNETIC AND PIEZO SIGNALS IS PRODUCED.  
WHEN BOTH JACKS ARE USED, THIS OUTPUT WILL PRODUCE THE BUFFERED PIEZO SIGNAL ONLY; THE MAGNETIC SIGNAL IS DIVERTED TO THE MAGNETIC/STEREO OUTPUT.